



DECT Phone Setup Guide

- 1 Connect your base station to power and ethernet.
- 2 Wait until 3 blue lights appear and stay on   
Note: The device may reboot itself during the first bootup. Give it ample time to configure itself.
- 3 Hold the  button for approx. 7 sec until the blue  light begins blinking.
- 4 Power on your handset (hold the red “end-call” button).
- 5 Press subscribe, then press subscribe again when “Base1” is highlighted on-screen.
- 6 The base station’s  light should be flashing while the handset is searching.
- 7 When your handset discovers the base station, you will see “Fongo Works” followed by numbers & letters.
- 8 Press subscribe again.
- 9 Repeat steps 3-8 for any additional handsets you want to pair.

Once successfully paired, your handset’s screen will show the extension number above the time, then the extension name below the time.

