



GRP 2615
GRP 2624
GRP 2612w



Connecting your phone to WiFi

- 1 Enter the menu by pressing the button in the center of the directional arrows
- 2 Select "System"
- 3 Select "Wi-Fi Settings"
- 4 Ensure Wi-Fi is enabled*
- 5 Select "Scan"
- 6 When you see your Wi-Fi network appear, scroll to it and press "Connect"
- 7 Enter your password, then press the OK

*If Wi-Fi is disabled, simply toggle left or right using the directional arrows to enable it

